

# Electrical safety





Never put fingers or objects into outlets





Keep plugged in appliances  
away from water





DANGER  
ELECTRICAL  
HAZARD  
KEEP  
OUT



FOR EMERGENCIES 1-866-436-7847

# Obey warning signs around electricity



FOR EMERGENCIES 1-866-436-7847





# Keep away from electrical boxes





# Never fly a kite near a power line





# Stay out of trees near power lines





Never go after a ball or Frisbee that has gone into a substation







# Never go near a downed power line

